

FRAME OUT OF ORDER

- **Unplug the damaged frame, this frame is seen as a Virtual Frame in Lake Controller. Close Lake Controller.**
- **Plug a new frame in the network only on primary network**
 - **Use lake update to verify Firmware and if necessary upgrade + cycle power.**
 - **Open Lake Controller**
 - **If necessary set Dual Redundancy of the new frame, and cycle power. Plug the secondary network.**
- **Open the system file.**
- **HOME / MODULE and select one module of the Virtual Frame**
- **Copy/Paste Replace, select the online Frame**
- **Complete Replace**
- **Store the system File**

Pascal GUILLAUME
DV2 – ADAMSON
ZAC Euro Moselle
2 rue de la Gillière
57140 NORROY LE VENEUR
FRANCE

BP 726
57147 WOIPPY CEDEX
France

Tel : +33 (0)387 30 00 00

pguillaume@dv2.fr