

BIG PA SETUP

1 – Warm Up / GroundWork

- **Build a small configuration using one frame for each system**
Example : 2 LM44 as driver / 1 PLM MAINL / 1 PLM MAINR / 1 PLM SUBL / 1 PLM SUBR / 1 PLM DLYL / 1 PLM DLYR...
- **Load preset using module or frame preset**
- **Build Lake controller Configuration OnLine : Pages and Groups**
- **Setup Dante Configuration**
- **System File STORE and FRAME PRESET STORE (Show_BASE)**
- **SAVE the Frame Preset Library of all frames (PLM Preset Manager)**

2 – On Site

- **For each Rack, check Firmware version on Front Panel or using Lake Update and if necessary upgrade + cycle power.**
- **Load and Recall each Frame preset with PLM Preset Manager into the Right Amps.**
- **Check Connection (Pink Noise or LoadSmart Verification)**
- **Build the Network**
- **Start Lake Controller and Load Modules in the right Page**
- **Check Groups**
- **Check NAME CONFLICTS**
- **SYSTEM STORE + Frame Preset STORE (Show_BASE_Time)**
- **Check Dante configuration with Dante Controller and Tune the PA**
- **SYSTEM STORE + Frame preset STORE (Show_TUNED_Time)**

Pascal GUILLAUME
DV2 – ADAMSON
ZAC Euro Moselle
2 rue de la Gillière
57140 NORROY LE VENEUR
FRANCE

BP 726
57147 WOIPPY CEDEX
France

Tel : +33 (0)387 30 00 00

pguillaume@dv2.fr