

## **SETUP using Module**

- **Verify Firmware version on Front Panel or, using Lake Update, and, if necessary, upgrade + cycle power.**
- **Front Panel : Menu/Frame/Frame Rst/Soft Reset or recall a Blank Frame Preset with a Frame label as ID ....**
- **Build the Network**
- **Start Lake Controller, HOME/MODULE load and select Module**
- **MODULE Recall + Output Routing**
- **Assign to Groups**
- **SYSTEM STORE + Frame Preset STORE (Show\_BASE\_Time)**
- **Check Connection (Pink Noise or LoadSmart Verification)**
- **Tune the PA**
- **SYSTEM STORE + Frame preset STORE (Show\_TUNED\_Time)**

Pascal GUILLAUME  
DV2 – ADAMSON  
ZAC Euro Moselle  
2 rue de la Gillière  
57140 NORROY LE VENEUR  
FRANCE

BP 726  
57147 WOIPPY CEDEX  
France

Tel : +33 (0)387 30 00 00

[pguillaume@dv2.fr](mailto:pguillaume@dv2.fr)